



# Sunbeam

**HOUSEHOLD PRODUCTS**  
**12 SPEED DELUXE MIXER**



		1998	
X	PART NO.		

2356-1 (OLD 1921)		X				
2358-1 (OLD 1930)			X			
2359-1 (OLD 1940)				X		
2360-1 (OLD 1960)					X	
2360-2						X
2359-040						X
BASIC PARTS	X					

**120 V., 60 HZ., 1.9 Amps.**

	DESCRIPTION	STATUS	PART #	QUANTITY REQ'D					
				1	2	3	4	5	6
31	LOWER HOUSING (WHITE)		013769-000-000	1			1	1	
	(CHROME)	OB	013769-005-000			1			
	(CHROME)		019569-010-088						1
	(WHT W/LIGHT HSG)		013769-010-000		1				
31A	ASEM, LIGHT HOUSING**		018318-025-000		1				
31C	LAMP - 6 VOLT **		030129-000-000		1				
31D	SCREW (LIGHT HSG ASEM)**	OB	018179-000-000		1				
32	SCREW HGT ADJ		019587-001-000	1					
33	NUT, HGT ADJ	OB	014257-000-000	1					
34	WHIPPER, W/DR BUTTON		013758-000-000	1					
35	WHIPPER, SQUARE		013759-000-000	1					
36	DOUGH HOOK (INNER)		030084-010-000	1					
37	DOUGH HOOK (OUTER)		030083-010-000	1					
39	BOWL, SMALL SS		022803-000-000	1	1	1			1
	SMALL GLASS		027481-000-000				1	1	
40	BOWL, LARGE SS		022802-000-000	1	1	1			1
	LARGE GLASS		027482-000-000				1	1	
41	ASEM, TURNTABLE (GRAY)		019449-000-855	1					
	(BLACK)		019449-000-090		1	1	1	1	1
42	STAND ONLY	OB	019371-100-805	1			1	1	
42	STAND ONLY		019548-000-000			1			1
42	STAND ONLY		019371-100-837		1				
43	FEET		013869-000-000	4					
44	TRIGGER (CHROME)		017939-000-000	1					
45	SPRING, TRIGGER		017942-000-000	1					
46	PIN, TRIGGER		017971-000-000	1					
47	STAND ASSY.		013768-000-000			1			
	STAND ASSY.		019537-000-837		1				
	STAND ASSY.		019537-000-805	1			1		
	STAND ASSY.		019547-005-000						1
48	ASEM, CORD (BLACK) **		019565-005-818	1					
	ASEM.CORD (BLACK) **		019565-030-090						1
	ASEM.CORD (BLACK) **		019565-005-090		1				
	ASEM.CORD (BLACK) **		019565-015-090			1	1	1	
**	INST. BOOK		030058-011-000	1					

**\*\* PARTS NOT SHOWN ON DRAWING  
OBI- OBSOLETE ITEM**

